


# EMS CX<sup>3</sup> - Modbus/EMS Interface

Cat. N° : 4 149 40



Contents	Pages
1. Description - Use .....	1
2. Range .....	1
3. Overall dimensions.....	1
4. Preparation - Connection .....	1
5. General characteristics .....	3
6. System architectures.....	8
6.1 Stand-alone.....	8
6.1.1 with local addressing.....	8
6.1.2 with remote addressing.....	9
6.2 Supervised.....	10
6.2.1 with local addressing.....	10
6.2.2 with remote addressing.....	12
7. Compliance and approvals .....	14

## 1. DESCRIPTION - USE

- . Module dedicated to Energy Management System (EMS CX<sup>3</sup>) use.
- . It performs conversion from the EMS CX<sup>3</sup> bus to Modbus RS485 protocol.

### Symbol:




## 2. RANGE

- . Cat. n° 4 149 40: EMS CX<sup>3</sup>/Modbus RS485 Interface

### Width:

- . 1 module. 17,8 mm width.

## 3. OVERALL DIMENSIONS




## 4. PREPARATION - CONNECTION

### Fixing:

- . On symmetric rail EN/IEC 60715 or DIN 35 rail


### Operating positions:

- . Vertical, Horizontal, Upside down, On the side




### Power Supply:

- . Mandatory in 12 VDC via the specific Power supply module Cat n° 4 149 45
- . Two ways:
  - via specific communication patch cords (cat. nos 4 149 07/08/09) to connect at the downstream through dedicated ports



via specific communication rails (cat. nos 4 149 01/02/03) to connect at the rear through dedicated connectors.



## 4. PREPARATION –CONNECTION (continued)

### Recommended tools:


. For fixing: flat screwdriver 5.5 mm (6 mm maximum).

### Data connection (EMS CX<sup>3</sup> modules inter-connection):


. Via specific communication patch cords (cat. nos 4 149 07/08/09)



Allow data transmission between the different EMS CX<sup>3</sup> modules. This type of connection is recommended when there are few EMS CX<sup>3</sup> modules, distributed all over the enclosure.




**Implementing:** with this configuration, the plastic protection cover of the backside communication ports on the EMS CX<sup>3</sup> module must be keep on.




**Note:** Sliding the form to the right or left is prohibited.

. Via specific communication rails (cat. nos 4 149 01/02/03).



. Allow data transmission between the different EMS CX<sup>3</sup> modules. This type of connection is recommended when there are several EMS CX<sup>3</sup> modules on the same DIN row.





## 4. PREPARATION –CONNECTION (continued)

### Data connection (EMS CX<sup>3</sup> modules inter-connection)

(continued):



**Implementing:** with this configuration, the plastic protection cover of the backside communication ports on the EMS CX<sup>3</sup> module must be removed.



. Via a mix between specific communication patch cords and communication rails in order to create a link between several rows

Two situations:

- Individually connected with communication rails.  
The communication patch cord allows to connect two rows.




- Individually connected with communication patch cords & communication rail.

## 4. PREPARATION –CONNECTION (continued)

### Data connection (EMS CX<sup>3</sup> modules inter-connection)


(continued):

The communication patch cords allow to connect EMS CX<sup>3</sup> module on a row and to connect two rows.



### Front USB port:

. Allows, if needed (e.g. for configuration), to connect the EMS CX<sup>3</sup> Modbus/EMS Interface to a computer via a “type B” micro USB/USB commercial cable.




. Via the Legrand - EMS configurator software (download for free) is possible to:

- test an EMS installation
- update the module’s firmware


..create a link between two modules with Link Functionality  
 configure the modules characteristics if the lateral DIP Switches remain on 0000 position (for the modules 4 149 30/32)  
 make the extended addressing procedure (see § 6.2.2)

### Modbus connection adapter (cod. LG-981825)



Used to wire a Belden 9842 or Belden 3106A (or equivalent) type cable.

Insert the cable into the terminals and tighten the screws.




See “System architecture chap. 6”

## 5. GENERAL CHARACTERISTICS

### Front face marking:


. By permanent ink pad printing (red line) and laser marking




### Lateral side marking:

. By laser.

left side: Standard and programming information



right side: cabling and traceability information




## 5. GENERAL CHARACTERISTICS (continued)

### Lateral side marking:

. Upper face.

Switch to insert the 120Ω termination resistance (see § 6.2.2 "RS485 Wiring diagram")





Marking indicating that the address of the Interface is the tenth of the Modbus address

### Signalling LEDs:


. Interface is equipped with 3 signalling LEDs:

- "ER": Communication error led → it blinks red if there is an error on the communicating bus
- "TX" and "RX": frame transmission and reception signalling led → they blink yellow when there is communication activity on the bus



### Multi-Functions button:




. Front face button as several functions:



## 5. GENERAL CHARACTERISTICS (continued)

### Multi-Functions button (continued):

. Gives information about the operating state on the module  
Possible states:

Led colour	State	Meaning
 red	Slow blinking	Error (e.g. addressing error)
	Fast blinking	System alarm detected (see Note*)
	Steady (pressing the multifunction button longer than 10 sec.)	Total reset [any firmware updates are preserved]
 green	Slow blinking	System process is running. Wait until the Led turns steady
	Fast blinking (pressing the multifunction button for 5 sec.)	put in "Stand-by" the EMS CX <sup>3</sup> module (no remote action and communication available)
	Steady	System OK, connection is running
 orange	Slow blinking	Waiting for firmware update
	Fast blinking	Device's firmware update in progress
	Steady	Start of FW update

### \* Note

#### . Possible system alarms detected by the Modbus/EMS Interface:

- loss of communication with an EMS module
- error in addressing procedure: possible mix between local and remote address (see § 6)
- duplicate function error: two EMS modules with the same function have the same address.

#### . To turn off the system alarm:

- solve the problem according to the indication of the alarm
- push the Multifunction button on the Interface → the led become steady green

5. GENERAL CHARACTERISTICS *(continued)*

**Link Functionality:**

. This function allows you to link two EMS CX<sup>3</sup> modules to create automatic actions that, once programmed, can run independently without a connection to a manager is needed.

The basic rule is the link between an event (circuit breaker that trip, a threshold exceeded, etc.) and an action accordingly (signalling, opening of a circuit by motorized control or contactor, etc.).

Possible associations are:

Event generator	Action module		
	Command: 4 149 32	State + Command: 4 149 31	State: 4 149 30
Measure: 4 149 18/19/20/21/ 22/23/24/25/27	✓	✓	✓ Only with the module configured remotely as shown: 
State: 4 149 29/30	✓	✓	✗ Simply configure the module remotely as "Replica"
State + Command: 4 149 31	✓	✓	✗ Simply configure the module remotely as "Replica"
DPX3 interface: 4 238 90	✓	✗	✓ Only with the module configured as shown: 
Circuit breakers S10	✓	✗	✓ Only with the module configured as shown: 

**Note:**

- association can only be of type 1 to 1 (1 event and 1 action).
- modules already associated cannot be used for other associations.
- all the configuring procedure will be done with the Configuration Software (available online for free). *[For more details refer to the Installation Manual of EMS CX<sup>3</sup> Configuration software]*

**5. GENERAL CHARACTERISTICS** *(continued)***Link Functionality** *(continued)*:

Modules compatible with "Link Functionality" feature: firmware versions and production date:

Cat n°	Firmware version	Production date indicated on the label stucked on the side of the module
4 149 18	all firmware versions	any production date
4 149 19	ver. ≥ 2.0.1	date ≥ 18W29
4 149 20	ver. ≥ 2.0.1	date ≥ 18W49
4 149 21	all firmware versions	any production date
4 149 22	all firmware versions	any production date
4 149 23	ver. ≥ 2.0.1	date ≥ 18W49
4 149 24	all firmware versions	any production date
4 149 25	all firmware versions	any production date
4 149 27	all firmware versions	any production date
4 149 29	ver. ≥ 2.0.1	date ≥ 18W49
4 149 30	ver. ≥ 2.0.2	date ≥ 18W32
4 149 31	ver. ≥ 2.0.6	date ≥ 18W45
4 149 32	ver. ≥ 3.0.2	date ≥ 18W39
4 149 36	ver. ≥ 2.0.4	date ≥ 18W38
4 149 37	ver. ≥ 2.0.4	date ≥ 18W43
4 149 40	ver. ≥ 3.0.8	date ≥ 18W34

**RS485 communication port's characteristics:**

- . Programmable addresses: from 1 to 247
- . Galvanically isolated respect to auxiliary supply
- . Standard RS485 3 wires, half-duplex (+, -, Signal ground); for the RJ45 connector, pin 4 (-), pin 5 (+) and pin 8 (SG)
- . Protocol Modbus® RTU
- . EMS CX<sup>3</sup>/RS485 interface automatically detects the Modbus parameters of other devices in the system and automatically sets its Modbus parameters.
- . Possible values:
  - Baud rate: 1,2 - 2,4 - 4,8 - 9,6 - 19,2 - 38,4 - 57,6 - 115,2 kbps
  - Parity bit: none, even, odd
  - Stop bit: 1 or 2

**Insulation voltage:**

- .  $U_i = 400 \text{ V}$

**Pollution degree:**

- . 2 according to IEC/EN 60898-1.

**Overvoltage category:**

- . III

**Dielectric strength:**

- . 2500 V

**Plastic material:**

- . Self-extinguishing polycarbonate.
- . Heat and fire resistant according to IEC/EN 60695-2-12, glow-wire test at 960° C.
- . Classification UL 94 / IECEN 60695-11-10: V1

**5. GENERAL CHARACTERISTICS** *(continued)***Ambient operating temperature:**

. Min. = -25° C. Max. = +70° C

**Ambient storage temperature:**

. Min. = -40° C. Max. = +70° C

**Protection Index:**

. Protection index of terminals against direct contacts:

IP2X (IEC/EN 60529).

. Protection index of terminals against solid and liquid bodies (wired device): IP 20 (IEC/EN 60529).

. Protection index of the front face against solid and liquid bodies: IP 40 (IEC/EN 60529).

. Class II, front panel with faceplate.

**Average weight per device:**

. 0,050 kg.

**Volume when packed:**

. 0,21 dm<sup>3</sup>.

**Consumption:**

. Values at 12 VDC

Configuration	W	mA
Stand-by	0,316	26,3
Communication	0,344	28,7

## 6. SYSTEM ARCHITECTURES

The EMS CX<sup>3</sup> is a polyvalent system and, according to the needs of the customer, can be set up and/or used as "Stand-alone" or "Supervised" system. Based on this choice the configuration and addressing methods are different.

Four possible architectures are provided:

### 6.1 Stand-alone system

6.1.1 with local addressing (through the track wheel)

6.1.2 with remote addressing (through a computer)

### 6.2 Supervised (Computer Supervisory System)

6.2.1 with local addressing

6.2.2 with remote addressing

### 6.1 Stand-alone system

. **Stand-alone** = autonomous system. To be used by the end-user if it is not necessary to have a computer for the supervision outside the envelope. Everything can be managed on site.

#### 6.1.1 Stand-alone system with local addressing (through the track wheel)

Local addressing advantages:


- No configuration software needed to set-up the installation
- **It is not necessary to use a computer to manage settings** (configurations, test, ...) and to use the system (visualize and be alerted, ...). Everything can be done through the Mini configuration module (local display, cat. no 4 149 36/37). [Refer to the technical sheet dedicated to this module for details].
- No communication Interfaces or gateways are required.
- Installation can be done without the intervention of a System Integrator

#### Programming procedure:

. For EMS CX<sup>3</sup> modules which need some: mandatory through the EMS CX<sup>3</sup> configurator (see § "Module configuration")

#### Addressing procedure:

- . For all EMS CX<sup>3</sup> modules: mandatory through the track wheel located on the top upper face of each EMS CX<sup>3</sup> modules
- . Marked from 0 to 9 in order to locally define the Modbus address of the EMS CX<sup>3</sup> modules




#### Note for Measure Module "3x single phase":

This module is to be consider as 3 modules with 3 different Modbus Address. The module takes automatically the two addresses immediately following to the programmed one (e.g. Programmed address = 2, Addresses of the module 2, 3, 4)

#### Consequences of the local addressing mode (through the track wheel):

- . Each device of the system must be addressed.
- . Addresses available: from 1 to 9
- . Address 0 not permitted
- . It is possible to assign to several devices the same address with the purpose of grouping different functions, **because they are related to the same electrical circuit**. For example, it is possible to assign the same address to a signalling auxiliary module (cat. no 4 149 29), a universal control module (cat. no 4 149 32), a measuring module, and so on. In this way on the EMS CX<sup>3</sup> mini configuration module (local display) the grouped function will be displayed as a unique "device" with all grouped functions. [Refer to the schemes hereunder]



#### Note for the mini configuration module (local display)

- . It is necessary to assign the mini configurator a different address from all the other EMS CX<sup>3</sup>modules through the device programming menu.
- . The mini configuration module can be placed everywhere in the EMS CX<sup>3</sup> bus



## 6. SYSTEM ARCHITECTURES

### 6.1 Stand-alone system *(continued)*

#### 6.1.2 Stand-alone system with remote addressing (through a computer)


Remote addressing advantages:


- Whole configuration (addresses and functions) can be set up through the EMS Configuration software
- Configuration software available for free
- **Automatic detection of the EMS CX<sup>3</sup> modules** installed in the system (characteristics, functions, configuration...)
- **Increased settings possibilities: load shedding function**
- Increased addressing: **up to 30 Modbus addresses in a system**

#### Programming procedure:

. For EMS CX<sup>3</sup> modules which need some: mandatory via the configuration software *(see § "Module configuration")*

#### Addressing procedure:





 The track wheel must be left in position "0".

. It is not necessary to assign an address via rotary; **The track wheel must be left in default position "0"**.

. All the addressing/configuring procedure will be done with the Configuration Software (available online for free)

. With remote addressing, the software does the automatic detection of modules installed in the system, but the supervision is not possible until the user assigns the remote address and all the characteristics to each module.

**Note: it is mandatory to connect the computer to the Mini configuration module with an USB-micro USB cable.** *[For more details, refer to the technical data sheet of the Mini configuration module EMS CX<sup>2</sup>]*



#### Note for Measure Module "3x single phase":

This module is to be consider as 3 modules with 3 different Modbus Address. The module takes automatically the two addresses immediately following to the programmed one (e.g. Programmed address = 2, Addresses of the module 2, 3, 4)

## 6. SYSTEM ARCHITECTURES


### 6.1 Stand-alone system *(continued)*

#### 6.1.2 Stand-alone system with remote addressing (through a computer) *(continued)*

#### Consequences for the system architecture:

- for 1 mini configuration module (cat. no 4 149 36/37)
  - o up to **30 EMS CX<sup>3</sup> modules** (e.g. 30 devices grouped per functions with addresses from 1 to 30)

It is possible to assign to several devices the same address with the purpose of grouping different functions, **because they are related to the same electrical circuit**. For example, it is possible to assign the same address to a signalling auxiliary module (cat. no 4 149 29), a universal control module (cat. no 4 149 32), a measuring module, and so on. In this way on the EMS CX<sup>3</sup> display or in a supervision system the grouped function will be displayed as a unique "device" with all grouped functions. *[Refer to the schemes here under]*



#### Note for the mini configuration module (local display)

- . It is necessary to assign the mini configurator a different address from all the other EMS CX<sup>3</sup> modules through the device programming menu.
- . The mini configuration module can be placed everywhere in the EMS CX<sup>3</sup> bus

### 6.2 Supervised system (Computer Supervisory System)

. **Supervised system** = System to be used through a Computer Supervisory System to remotely read data from the EMS CX<sup>3</sup> devices and/or do operations on these devices (e.g. commands of a motor driven or contactor ...).

#### 6.2.1 Supervised system-with local addressing (through the track wheel)

Local addressing advantages:


- No configuration software needed to set-up the installation
- Installation can be done without the intervention of a System Integrator

#### Programming procedure:

For EMS CX<sup>3</sup> modules which need some: mandatory via the configuration software (see § "Module configuration")

#### Addressing procedure:

- . For all EMS CX<sup>3</sup> modules: mandatory through the track wheel located on the top upper face of each EMS CX<sup>3</sup> modules
  - . Marked from 0 to 9 in order to locally define the Modbus address to EMS CX<sup>3</sup> modules
- In this system the Modbus address of an EMS CX<sup>3</sup> module device or group of modules (several functions) is obtained considering the address of the interface Modbus/EMS CX<sup>3</sup> Interface as tenth and the address of a device or group of function as unit (e.g. Interface address 1 = 10 → address of module n° 5 = Modbus address 15)



#### Note for Measure Module "3x single phase":

This module is to be consider as 3 modules with 3 different Modbus Address. The module takes automatically the two addresses immediately following to the programmed one (e.g. Programmed address = 12, Addresses of the module 12, 13, 14)

## 6. SYSTEM ARCHITECTURES *(continued)*

### 6.2 Supervised system (Computer Supervisory System) *(continued)*


#### 6.2.1 Supervised system with local addressing (through the track wheel) *(continued)*

#### Consequences of the local addressing mode (through the track wheel):

- . Each device of the system must be addressed.
- . Rotary position available: from 1 to 9
- . Rotary position in 0 not permitted

It is possible to assign to several devices the same address with the purpose of grouping different functions, **because they are related to the same electrical circuit**. For example, it is possible to assign the same address to a signalling auxiliary module (cat. no 4 149 29), a universal control module (cat. no 4 149 32), a measuring module, and so on. In this way on the EMS CX<sup>3</sup> display or in a supervision system the grouped function will be displayed as a unique “device” with all grouped functions. *[Refer to the scheme hereunder]*

**Note:** In this configuration the Modbus address of an EMS CX<sup>3</sup> module device or group of modules (several functions) is obtained considering the address of the interface Modbus/EMS CX<sup>3</sup> Interface as tenth and the address of a device or group of function as unit (e.g. Interface rotary 1 = 10 and device rotary = 5 → Modbus address = 15)



#### Consequences for the system architecture:

- for 1 IP/Modbus gateway (cat. no 0 046 89):
  - o up to **81 Modbus address**
  - o mandatory limit of max. **9 Modbus/EMS CX<sup>3</sup> interfaces** or max. **1000 m of Modbus cable** (cable Belden 9842, Belden 3106A or equivalent) or max. **50 m of Category 6 cable** (FTP or UTP).
- for 1 Modbus/EMS CX<sup>3</sup> Interface (cat. no 4 149 40):
  - o up to **30 EMS CX<sup>3</sup> modules** (ex. 30 devices grouped per functions with addresses from 1 to 9)

**Note:** with local addressing, the Modbus/EMS CX<sup>3</sup> interface, does the automatic detection of modules (characteristics, functions, configuration...)

## 6. SYSTEM ARCHITECTURES *(continued)*

### 6.2 Supervised system (Computer Supervisory System) *(continued)*

#### 6.2.2 Supervised system-with remote addressing (through a computer)


Remote addressing advantages:

- Whole of configuration (addresses and functions) can be done a remotely through the EMS Configuration software
- Configuration software available for free
- **Automatic detection of the EMS CX<sup>3</sup> modules** installed in the system (characteristics, functions, configuration...)
- **Increased settings possibilities: load shedding function**
- Increased addressing: **up to 32 Modbus/EMS CX<sup>3</sup> interfaces**
- Increased addressing: **up to 247 Modbus addresses in a system**

#### Programming procedure:

. For EMS CX<sup>3</sup> modules which need some: possible through the lateral DIP-switches of each EMS CX<sup>3</sup> module or via the configuration software *(see § "Module configuration")*.

#### Addressing procedure:





. It is not necessary to address the EMS CX<sup>3</sup> modules. **The track wheel must be left in default position "0"**.

. All the addressing/configuring procedure will be done with the Configuration Software (available online for free)

. With remote addressing, the software does the automatic detection of modules installed in the system, but the supervision is not possible until the user assigns the remote address and all the characteristics to each module.

**Note: it is mandatory to connect the computer to the different Modbus/EMS CX<sup>3</sup> interface with an USB-micro USB cable (one interface at a time).** *[For more details, refer to the § "Front USB port" of this document]*




#### Note for Measure Module "3x single phase":

This module is to be consider as 3 modules with 3 different Modbus Address. The module takes automatically the two addresses immediately following to the programmed one (e.g. Programmed address = 2, Addresses of the module 2, 3, 4)

## 6. SYSTEM ARCHITECTURES *(continued)*

### 6.2 Supervised system (Computer Supervisory System) *(continued)*

#### 6.2.2 Supervised system-with remote addressing (through a computer) *(continued)*



#### Consequences for the system architecture:

- for 1 IP/Modbus gateway (cat. no 0 046 89):
  - o up to **247 Modbus address**
  - o Because of Modbus: mandatory limit of max. **32 Modbus/EMS CX<sup>3</sup> interfaces** or max. **1000 m of Modbus cable** (cable Belden 9842, Belden 3106A or equivalent) or max. **50 m of Category 6 cable** (FTP or UTP).
- for 1 Modbus/EMS CX<sup>3</sup> Interface (cat. no 4 149 40):
  - o up to **30 EMS CX<sup>3</sup> modules or grouped modules** (e.g. 30 devices grouped per functions with addresses from 1 to 30)


It is possible to assign to several devices the same address with the purpose of grouping different functions, **because they are related to the same electrical circuit**. For example, it is possible to assign the same address to a signalling auxiliary module (cat. no 4 149 29), a universal control module (cat. no 4 149 32), a measuring module, and so on. In this way on the EMS CX<sup>3</sup> display or in a supervision system the grouped function will be displayed as a unique “device” with all grouped functions. *[Refer to the scheme up here]*

## 6. SYSTEM ARCHITECTURES *(continued)*

### 6.2 Supervised system *(continued)*

#### 6.2.2 Supervised system with remote addressing *(continued)*

RS485 Wiring diagram:



(2) 4 149 01/02/03 - 4 149 07/08/09

**Note:** it is not necessary to dedicate a RS485 / IP gateway for the EMS CX<sup>3</sup> system. It is possible to mix several RS485 devices.

## 7. COMPLIANCE AND APPROVALS

### Compliance to standards:

- . Compliance with Directive on electromagnetic compatibility (EMC) n° 2014/30/EU
- . Compliance with low voltage directive n° 2014/35/EU.
- . Electromagnetic Compatibility:  
IEC/EN 61131-2

### Environment respect - Compliance with EU directives:

- . Compliance with Directive 2011/65/EU as amended by Directive 2015/863 (RoHS 2) on the restriction of the use of certain hazardous substances in electrical and electronic equipment.
- . Compliance with REACH regulation (1907/2006): at the date of the publication of this document no element of the SVHC substance list (updated on 27/06/2018) is present in these products.
- . WEEE directive (2012/19/EU): the sale of this product is subject to a contribution to eco-organisations in each country responsible for managing end-of-life products in the field of application of the European Waste Electronic and Electrical Equipment Directive.

### Plastic materials:

- . Halogens-free plastic materials.
- . Marking of parts according to ISO 11469 and ISO 1043.

### Packaging:

- . Design and manufacture of packaging compliant to decree 98-638 of the 20/07/98 and also to directive 94/62/CE.

### Environmental profile:

- . PEP document available

### Installation software:

- . XL PRO<sup>3</sup>.