L㔚 legrand®

ON

ON

Menu	▭
Areas ...	>
Address ...	>
Address test	
Language	>

3 sec.

OFF MANU

2 sec

OFF AUTO

5 min

* USB

← Mini USB

For more information about the operation of this tool, please consult the
"Addressable self-testing unit implementation manual"

(*) Not supplied

LE03191AB