

BEVESTIGINGSHOEK 90°				
SB500(S)	SB501(S)	SB502(S)	SB503(S)	SB504(S)
				<p>Voorbeeld:</p> <p>SB500 = </p> <p>SB500S = </p>
SB505(S)	SB551(S)	SB552(S)	SB556(S)	
BEVESTIGINGSSTRIP				
Bev.strip 1 gats	Bev.strip 2 gats ⁽¹⁾	Bev.strip 3 gats ⁽¹⁾	Bev.strip 4 gats ⁽¹⁾	
 Ref. Formaat gat SB50606(S) M6 SB50608(S) M8 SB50610(S) M10 SB50612(S) M12				
	SB507(S)	SB508(S)	SB509(S)	
Z-BEUGELS		U-BEUGELS		
SB511(S)	SB513(S)	SB514(S)	SB515(S)	
HOEKBEUGELS				
Hoekbeugel "stompe hoek" 45°		Hoekbeugel "scherpe hoek" 45°		
SB524(S)		SSB532(S)		
BEVESTIGING T-STUK				
T-stuk	T-stuk		90° T-stuk	
SB554(S)	SB603(S)		SB606 ⁽²⁾	

(1) Bevestigingsstrips – gaten geplaatst op 45 mm vanaf het midden (2) SB606 is niet leverbaar in RVS