

## METERBOX FLASHING INSTRUCTION SHEET

### FLASHING KITS

Part No.	Fits Meter Box
44336	NDC1, NDC1S, NDHB
45035	DC1, DC1S
45050	DC2, DC2S, DWP2, DHB2, NP2
46040	DCB1S, M1, DS1, NIMB
46060	DS2, M2
46550	DC3, DC3S, DWP3, NP3, DHB3
46565	DC4, DC4S
49565	DC5, DC5S

### INSTRUCTIONS

1. Attach bottom flashing first, fold tabs as per diagram.
2. The attach side flashings.
3. Attach top flashing last, fold tabs as per diagram.
4. Drill and rivet flashings to Meterbox using sealant.

