

# Firmware Release Notes



---

**Version:** 4.0.36 / Build 52138/ Release Notes

**Release Status:** General Availability (GA)

**Date:** March 27<sup>th</sup>, 2026

---

## Release Overview

4.0.36 Firmware is a **General Availability (GA) Release** for Linkeo Data Center. This release may include performance and productivity improvements, support for new products and accessories, new features and enhancements, bug fixes, and general fixes for specific model families.

## Applicability

This firmware release applies to the following products.

<i>Product Group</i>	<i>Model</i>
PDU's	Linkeo Data Center
Sensors	Legrand wireless sensors for PDU's

## General Guidelines for this Release

Some custom-engineered models may not be supported by this release. Please check the **Support & Compatibility** section below or contact Legrand Support if you are unsure of the model number of your unit—it is typically viewable from the GUI's *Device Information* page and is also printed on a label located on the device.

*Note:* Do NOT upgrade ANY other Legrand model(s) to 4.0.36 Firmware (other than what is listed in the Applicability table above) because the unit may either not be compatible with this Firmware or may have been built after this release entered our System Tests and installing it may result in the unit becoming non-functional.

*Note:* Do NOT downgrade your new product(s) to any prior-Firmware release. Due to significant internal enhancements in 4.0.36, a downgrade from Release 4.0.36 Build 52138 to ANY prior firmware release is NOT SUPPORTED. Please contact Legrand Support with any questions.

## Release Highlights

### New Features & Enhancements

<i>Issue ID</i>	<i>Description</i>
<b>86628</b>	<p>The delivery of this intermediary firmware is essential for managing the transition from versions 4.0.xx to the coming 4.3.50 release and beyond. It includes the updated Base Firmware and Bootloader, ensuring your system is ready for future updates.</p> <p>Once you have upgraded to version 4.0.36, we strongly recommend proceeding to version 4.3.50 as soon as it is available to ensure full performance.</p> <hr/> <p>The 4.0.36 version does not allow firmware downgrading.</p>

Please consult the appropriate User Guide for more information on these firmware features at <https://www.legrand.com/datacenter/int-en/linkeo-pdu-support>

### Upgrade Matrix (Path for Upgrades)

This firmware release is intended for factory shipments and firmware upgrades on the units/models stated in the Applicability table above.

<i>Firmware Version</i>	<i>Upgrade Steps</i>
<b>4.0.3x</b>	» 4.0.36

### Downloads

The following supplemental files can be downloaded at <https://www.legrand.com/datacenter/int-en/linkeo-pdu-support>

- User Guides

**Historical firmware** version downloads can be found on <https://www.legrand.com/datacenter/int-en/linkeo-pdu-support>

### Release Package Details

The 4.0.36 Firmware is a General Availability release package and will be posted on the Legrand Data Center website at <https://www.legrand.com/datacenter/int-en/linkeo-pdu-support>

#### 4.0.36 Package

Components for Linkeo Data Center Products:

- “PDU\_LDC\_ReleaseNotes\_4.0.36-52138.pdf” (this file)
- A firmware release (binary): PDU\_LDC\_040036-52138.bin

#### **General Upgrade Instructions** (*stand-alone upgrade from the browser-based user interface*)

- Enable JavaScript in your browser before logging into the unit to start the upgrade process.
- Follow instructions in the proper device User Guide. Please read the entire upgrade instructions before starting an upgrade.

If you have any questions, or cannot follow the instructions in the User Guide, please STOP and contact Legrand Support for further instructions.

#### Contact Us

For information on product offers or technical support needs, please contact our local customer service.

You can find details on our Legrand website.

Link: <https://www.legrand.com/en/world-presence>