



system components (continued)




3468 50



3499



3469 91



3501/2



3501K

Interface with other systems

Pack	Cat. Nos.	Interface
1	3461 50	8 wire/2 wire interface 6 DIN rail modules
1	3468 91	IP/2 wire interface 10 DIN rail modules

Expansion interfaces

1	3468 50	Apartment interface Connects a private video door entry system and MyHOME automation system in the apartment keeping it isolated from the main system distribution. The use of the internal installation within the apartment does not occupy the main block riser. 4 DIN rail modules
1	3468 51	Installation expansion module Allows increase in distance between entrance panel and handset, increase in number of devices installed, creation of risers with independent entrance panels. 4 DIN rail modules

Bell accessories

1	3369 10	Additional bell
1	3468 33	Floor call input device for door bell

Other accessories

1	3499	Line terminator To be used to terminate the riser or apartment line, when the last installed device is not fitted with line closing micro switch
1	3369 05	BUS low smoke halogen free cable 2 conductor cable (200 m coil)
1	3469 04	BUS cable 2 conductor cable (200 m coil)

Universal speaker unit and expansion module

1	3469 91	Universal speaker unit Can be used to install the 2 wire audio system in new or refurbished systems, where push button panels of other manufacturers are present or required (mail boxes, patterned brass, compact sheet metal units, etc.), preset for a traditional speaker module. Universal speaker unit includes contacts for the connection of 8 call push buttons; to make systems with more push buttons (up to 56 using Cat. No. 3460 50 (see p.26) power supply and up to 24 with Cat. No. 3460 40 (see p.26) power supply) one or more key expansion modules must be used (1 every 8 push buttons)
1	3469 92	Expansion module For connecting more than 8 call push buttons to Cat. No. 3469 91 - max. 6 modules (56 calls max.) with power supply Cat. No. 3460 50, see p. 26. Max. 2 modules (24 calls max.) with power supply Cat. No. 3460 40, see p. 26

Configurators and kits

		Used to associate an address with the different system components
		Configurators (pack of 10 pieces)
1	3501/0	No. 0
1	3501/1	No. 1
1	3501/2	No. 2
1	3501/3	No. 3
1	3501/4	No. 4
1	3501/5	No. 5
1	3501/6	No. 6
1	3501/7	No. 7
1	3501/8	No. 8
1	3501/9	No. 9
1	3501/JMP	JMP
1	3501/SLA	SLA
		Configurator kits
1	3060 64	Configurator kit – 10 internal units
1	3060 65	Configurator kit – 20 internal units
1	3501K	Configurator site kit consists of : – 10 pieces for each type of configurator from 0 to 9 – 2 blue removable 8-clamp connectors – 2 green removable 2-clamp connectors – 1 configurator connection tool – 1 plastic adjustment tool
		Pliers
1	3502	Pliers for configurators