Llegrand

Legrand cabling system, LCS³ cat. 6_A angled patch panels to be equipped, connectors





0 337 75

Equipped with new-generation Quick-Fix for automatic (screwless) mounting on enclosure and cabinet uprights Universal mounting on all cabinets or enclosures Panels ensure automatic earthing of each connector Equipped with 4 concentric strand guides fixed at the rear

Pack	Cat.Nos	Angled patch panels - to be equipped
		19" panels - 1U
		Angled patch panel to be equipped with connectors
1	0 337 92	Takes up to 24 cat. 5e to cat. 8 RJ 45 connectors
		High Density angled panel to be equipped with connectors
1	0 337 94	Takes up to 48 cat. 5e to cat. 6 _A RJ 45 connectors
		Cat. 6 _A High Density RJ 45 connectors
6 6	0 337 73 0 337 75	

Legrand cabling system, LCS³ cat. 6_A accessories

0 337 56 0 337 57		0 337 59 0 337 55 0 337 66 0 337 59 0 337 55 0 337 66
Pack	Cat.Nos	Common accessories for flat and angled panels
10	0 337 56	Port blanking modules Separable blanking plate For covering 1 to 6 ports or 1 to 12 ports individually (High Density solutions)
1	0 337 59	Cord management 2 cable guides to be clipped onto new-generation Quick-Fix Provide side cord management Label-holder for identification
		Specific accessories for flat panels
1	0 337 55	Cassette for flat panels to be equipped
1	0 337 66	Cassette with shutters for flat panels to be equipped Removable empty cassette to be equipped with connectors, takes 6 cat. 5e to cat. 8 connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance Equipped with 6 individual shutters to protect RJ 45 connectors contacts For equipping flat panels
1	0 337 95	High Density cassette for flat panels to be equipped Removable empty cassette to be equipped with connectors, takes 12 cat. 5e to cat. 6 _A connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance For equipping flat panels
1	0 337 57	Blanking cassette To be used to fill gaps in the panel
		Specific accessory for angled panels
1	0 337 58	Cover Optimises air flow management in the enclosure