
Clegrand

Legrand cabling system, LCS³ cat. 5e angled patch panels to be equipped, connectors





0 337 53

Equipped with new-generation Quick-Fix for automatic (screwless) mounting on enclosure and cabinet uprights Universal mounting on all cabinets or enclosures Panels ensure automatic earthing of each connector Equipped with 4 concentric strand guides fixed at the rear

| Pack | Cat.Nos | Angled patch panels - to be equipped |
|--------|----------------------|--|
| | | 19" panels - 1U |
| | | Angled patch panel to be equipped with connectors |
| 1 | 0 337 92 | Takes up to 24 cat. 5e to cat. 8 RJ 45 connectors |
| | | High Density angled panel to be equipped with |
| 1 | 0 337 94 | connectors Takes up to 48 cat. 5e to cat. 6 _A RJ 45 connectors |
| | | Cat. 5e High Density RJ 45 connectors |
| 6 6 | 0 337 53 0 337 54 | |
| | | in an angled panel or a zone distribution box to equipped Set of 6 RJ 45 connectors UTP |

Legrand cabling system, LCS³ cat. 5e accessories

| 199 | | | |
|------------|----------------------|---|---|
| 0 337 56 | | 0 337 59 0 337 55 0 337 66 | |
| | | | |
| 0 337 57 | | 0 337 58 | |
| Pack | Cat.Nos | Common accessories for flat and angled panels | |
| 10 | 0 337 56 | Parters Port blanking modules Separable blanking plate For covering 1 to 6 ports or 1 to 12 ports individually (High Density sowlutions) | |
| 1 | 0 337 59 | Cord management 2 cable guides to be clipped onto new-generation Quick-Fix Provide side cord management Label-holder for identification | |
| | | Specific accessories for flat panels | |
| | | Cassette for flat panels to be equipped | |
| 1 | 0 337 55 | Removable empty cassette to be equipped with connectors, takes 6 cat. 5e to cat. 8 connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance For equipping flat panels | , |
| 1 | 0 337 55 0 337 66 | Removable empty cassette to be equipped with connectors, takes 6 cat. 5e to cat. 8 connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance | |
| | | Removable empty cassette to be equipped with connectors, takes 6 cat. 5e to cat. 8 connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance For equipping flat panels Cassette with shutters for flat panels to be equipped Removable empty cassette to be equipped with connectors, takes 6 cat. 5e to cat. 8 connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance Equipped with 6 individual shutters to protect RJ 45 connectors contacts | , |
| 1 | 0 337 66 0 337 95 | Removable empty cassette to be equipped with connectors, takes 6 cat. 5e to cat. 8 connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance For equipping flat panels Cassette with shutters for flat panels to be equipped Removable empty cassette to be equipped with connectors, takes 6 cat. 5e to cat. 8 connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance Equipped with 6 individual shutters to protect RJ 45 connectors contacts For equipping flat panels High Density cassette for flat panels to be equipped Removable empty cassette to be equipped with connectors, takes 12 cat. 5e to cat. 6 _A connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance | , |
| 1 | 0 337 66 0 337 95 | Removable empty cassette to be equipped with connectors, takes 6 cat. 5e to cat. 8 connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance For equipping flat panels Cassette with shutters for flat panels to be equipped Removable empty cassette to be equipped with connectors, takes 6 cat. 5e to cat. 8 connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance Equipped with 6 individual shutters to protect RJ 45 connectors contacts For equipping flat panels High Density cassette for flat panels to be equipped Removable empty cassette to be equipped with connectors, takes 12 cat. 5e to cat. 6 _A connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance For equipping flat panels High Density cassette for flat panels to be equipped Removable empty cassette to be equipped with connectors, takes 12 cat. 5e to cat. 6 _A connectors Can be removed by simple pressing on the cassette, for ease of installation and maintenance For equipping flat panels Blanking cassette | , |