


ENSTO

LS11030WWFI
LS11060WWFI
LS11120WWFI
LS11240WWFI
LS11360WWFI
LS11720WWFI

W110.120AWWFI
W110.240AWWFI
W110.360AWWFI
W110.720AWWFI
W11015AWWFI
W11030AWWFI
W11060AWWFI





FI KytKentäohje

SV Kopplingschema

Legrand Finland Oy
Linnoitustie 11
02600 Espoo, Finland
Tel: +358 20 486 5010
www.legrand.fi

PEM4058