



Saves Your Energy

LUMINAIRE MAINTENANCE FACTOR VALUES

Environment	Cleaning intervals in years						
	1,0	1,5	2,0	2,5	3,0	3,5	4,0
Very clean	0,95	0,94	0,92	0,91	0,91	0,90	0,90
Clean	0,92	0,9	0,88	0,87	0,86	0,85	0,85
Normal	0,87	0,85	0,83	0,82	0,80	0,79	0,79
Dirty	0,83	0,8	0,78	0,76	0,74	0,73	0,72

Table contains only indicative values that may not reflect the achievable maintenance values in a particular installation.