# Double wireless lighting switch (peripheral) 0 648 94 - 0 677 24/74





This pack is a connected accessory which **requires** you to buy and install the connected starter pack and Céliane with Netatmo connected power outlets, switches (with dimmer option) and/or connected lighting micromodules first Céliane with Netatmo.



This product controls only Céliane with Netatmo connected switches (with dimmer option), lighting micromodules, cable outlets and power outlets Céliane with Netatmo.

#### **Pack contents**







Double wireless lighting switch

Finishing plate

Removable stickers

Frequency bands: 2.4 - 2.4835 GHz Power level: < 100 mW



www.legrand.fr


LEGRAND - Pro and Consumer Service - BP 30076 87002 LIMOGES CEDEX FRANCE • www.legrand.com

### Installing the double wireless lighting control

To pair the wireless control for lights and electrical devices with your connected installation, you should follow the instructions:

- in the Legrand Home + Control application (Settings/Add a new product section)
- or consult the user manual on legrand.fr

# Replacing the battery



## SIMPLIFIED **EU** DECLARATION OF CONFORMITY

The undersigned,

## Legrand

declares that the radio-electric equipment referred to in these instructions complies with directive 2014/53/EU.

The full text of the EU declaration of conformity is available on the following website:

www.legrandoc.com