






PW29236/37/38





PW29239/40/41






PW29242/43/44




1




	P (mm)	L (mm)
PW29236/39/42	265	182
PW29237/40/43	265	220
PW29238/41/44	265	265




3



4







5












PW29236/37/38




	L (mm)
12 modules	110
18 modules	155
24 modules	200






PW29239/40/41


1




2




3




4




5




6




7




8




9





10






	A	B
PW29236/39/42	257	125
PW29237/40/43	257	163
PW29238/41/44	257	208



PW28771/81/91



⚠ Consignes de sécurité

Avant toute intervention, couper le courant. Respecter strictement les conditions d'installation et d'utilisation.