









PW29245/46/47






PW29248/49/50




PW29242/43/44






PW28512/18/24



PW28500






PW28501/02/03









PW29245/46/47




3






PW29248/49/50


1




2




3





4




5




6




7






8





	A	B
PW29242/45/48	257	125
PW29243/46/49	257	163
PW29244/47/50	257	208



⚠ Consignes de sécurité

Avant toute intervention, couper le courant. Respecter strictement les conditions d'installation et d'utilisation.