



0 570 18



x 2



x 2



x 4



x 1



x 2



x 2








x 1




x 4




x 4






1


M8x30
5...6 Nm




2




3







1




2




3








4




5








1




2




1




2







1



2




www.legrand.com








0 580 31/32/33/34/37

3



4





	Prêt pour la charge / Ready for charging / Pronto per la carica / Pronto para a carga / Listo para la carga / Έτοιμο για φόρτιση / Klaar voor het laden
	Charge en cours / Charging in progress / Carica in corso / Carregamento em curso / Cargando / Φόρτιση σε εξέλιξη / Bezig met opladen
	Charge en attente / Waiting to charge / In attesa di ricarica / A aguardar carregamento / En espera de carga / Σε αναμονή φόρτισης / Wachten op laden
	Défaut / Error / Errore / Erro / Error / Σφάλμα / Fout