STOP&GO automatic resetting

4 062 88

Pack	Cat.Nos	STOP&GO automatic resetting		
		For automatic resetting of 1 module per pole RCCBs and RCBOs up to 63 A STOP&GO is used in the event of unwanted tripping generated by temporarily electrical disturbances or other external events. Can take one control auxiliary and one signalling auxiliary. The signalling auxiliary must be placed between the STOP&GO and the control auxiliary. No tool required for assembling		
		Automatic resetting function	Control voltage	No. of modules
1	4 062 88		230 V~	2
		Automatic resetting + periodic self-test function		
1	4 062 89		230 V~	2

1: Products to be submited to local tests to ensure a perfect functioning

Voltage surge protectors
p. 76

Keor UPS
p. 700

Manual transfer switch DX³ and accessories

4 063 14

4 063 19

Technical characteristics **see e-catalogue**

Pack	Cat.Nos	Manual transfer switch (MSI)
		For manually switching between the mains and an alternative power supply. Allow to restore power on pre-designated and/or critical circuits in case of a power failure of the main supply. For DX³ MCBs and remote trip isolating switches Installation principle - see e-catalogue
1	4 063 14	For 2P 2-module devices
1	4 063 15	For 3P 3-module devices
1	4 063 16	For 4P 4-module devices
		Front external rotary handles Allow the manual control (open/close) of a modular device without opening the enclosure For all DX³, TX³ and RX³ devices from 2P upwards Supplied with bracket, connection rod, handle, self-adhesive drilling template and connection accessories Installation principle - see e-catalogue
1	4 063 19	Black handle
1	4 063 20	Yellow and red handle
		Wiring management accessories
		Insulating shields
1	4 063 05	For 1 module per pole MCBs For separation between the terminals of the MCB, when using high cross section cables
		Spacing unit with feedthrough
10	4 063 07	0.5 module Allows cables to run between two modular devices and creates an air channel in order to limit temperature rise
		Terminals for aluminium cables
1	4 063 10	For 1 and 1.5 module/pole MCBs up to 63 A
1	4 063 11	For 1.5 module/pole MCBs and remote trip isolating switches from 80 A to 125 A
		Safety and maintenance accessories
		Sealable screw covers
2	4 063 04	For 1 and 1.5 module per pole MCBs (set of 4)
1	4 063 12	For 1.5 module per pole MCBs (set of 4)
		Terminal shield
1	4 063 06	For 1.5 module/pole MCBs (set of 2)
		Padlocking To lock the handle of a modular device during maintenance
1	0 227 97	Large padlock, Ø6 mm, 50 mm length Supplied with two keys and labels
3	4 063 13	Small padlock, Ø5 mm
2	4 063 03	Support for one padlock (for small or large model) For locking the handle of the modular devices (MCBs, RCCBs, RCBOs or isolating switches) in OFF position