










The instructions for installation and use must be strictly observed in order to avoid the risk of electric shock or fire.



C1. C2:

MAX 2x 1.5mm² 2.5mm²

MAX 2x 2.5mm²


6mm²

C1.C2.

Wiring examples


Thanks to its control circuit with integrated power and protection, you no longer need to install a circuit breaker 2A to protect the control circuit if you wire a contact between C1 and C2.

For the protection of the Connected Contactor, it is recommended to use a circuit breaker or a gG fuse with current rating < 20A.



*: Non-functional consumption measurement when controlling a single line or a three lines power contactor by a connected contactor.

N (neutral) = blue L (Line) = Everything but blue and green/yellow Line after contact = usually purple, orange...







no active live part is accessible.



Turn on the power at the general circuit breaker*
once the installation
completed and controlled**





(3) Finalize the installation in the Legrand Home + Control app

Download the Home + Control App and follow the instructions for adding the connected product in your setup.









You also have the option of controlling your installation via a voice assistant. and can customize your scenarios via the Home + Control App.











Automatic Mode










ON/OFF Mode





Reset a Connected Contactor to remove it from a connected installation

Press the configuration button of the Connected Contactor (> 5 seconds) until the configuration indicator lights up in fixed red. It is no longer associated with the gateway present in the installation.





www.legrand.fr/reference/412171

LEGRAND - Pro and Consumer Service - BP 30076 87002 LIMOGES CEDEX FRANCE • www.legrand.com

UE SIMPLIFIED DECLARATION OF CONFORMITY

The undersigned,

Legrand

declares that the radio equipment listed on this instruction sheet are compliant to the directive 2014/53/UE.

The full text of the UE declaration of conformity is available at the following website:

www.legrandoc.com