

Contents

1.0 ABSTRACT	2
2.0 DATA MESSAGE DESCRIPTION	3
2.1 Parameters description.....	3
2.2 Data format.....	4
2.3 Description of CRC calculation.....	5
2.4 Error management	5
2.5 Timing.....	6
3.0 COMMANDS	7
4.0 VARIABLES.....	8
5.0 SETUP PARAMETERS	15

Rev	DESCRIPTION	Date	Sw
B	Formal revision	10/05/2016	➤ 5.08

1.0 ABSTRACT

Physical level

The electrical communication line complies with the EIA-RS485 standard in half-duplex modality. In this case, as only two wires are used, only one instrument at a time can engage the line; this means that there must be a master which polls the slave instruments so the demand and the request are alternated.

On the same line only 32 instruments can be attached (master included). In order to increase the number of the slave instrument, the necessary repeaters must be used.

The communication parameters are :

Baud rate	: programmable (device dependant)
bit n.	: 8
stop bit	: 1
parity	: programmable (device dependant)

Data link level

The data are transmitted in a packet form (message) and are checked by a word (CRC). See the description of the data packet in the next paragraphs for more details.

Application level

The communication protocol used is MODBUS / JBUS compatible.

Up to 255 different instruments can be managed by the protocol.

There are no limitations to the number of possible retries done by the master.

A delay between the response from the slave and the next command could be necessary and it is specified for each device (timing).

2.0 DATA MESSAGE DESCRIPTION

The generic data message is composed as following :

Device address	Functional code	Data	CRC word
----------------	-----------------	------	----------

Two answers are possible :

Answer containing data

Device address	Functional code	Data	CRC word
----------------	-----------------	------	----------

Error answer

Device address	Functional code + 0x80	Error code	CRC word
----------------	---------------------------	------------	----------

2.1 Parameters description

Device address : device identification number in the network.
It must be the same for the demand and the answer.
Format : 1 BYTE from 0 to 0xff
0 is for broadcast messages with no answer

Functional code : command code
Used functional code :
Format : 1 BYTE
0x03 : reading of consecutive words
0x10 : writing of consecutive words

Data : they can be
- the address of the required words (in the demand)
- the data (in the answer)

CRC word : it is the result of the calculation done on all the bytes in the message

2.2 Data format

The following types of format are used for the data values :

- * U_WORD : one WORD - unsigned
- * S_WORD : one WORD - signed
- * UD_WORD : two WORDS - unsigned
- * SD_WORD : two WORDS - signed

If the required data is in a DWORD format, 2 WORDS are transmitted and the MSW comes before the LSW
 (depending on the setting in the NEMO 96 : **big endian / little endian / swap WORDS**)

MSB	LSB	MSB	LSB
Most Significant WORD	Least Significant WORD		

Example : 1000 = 0x 03 e8 or
 0x 00 00 03 e8 (if UDWORD)

MSB	LSB	MSB	LSB
0x00	0x00	0x03	0xe8



2.3 Description of CRC calculation

The following is an example of the CRC calculation in C language.

```

unsigned int calc_crc (char *ptbuf, unsigned int num)
/*
 *      *****
 *      Descrizione : calculates a data buffer CRC WORD
 *      Input       : ptbuf = pointer to the first byte of the buffer
 *                  num    = number of bytes
 *      Output      : //
 *      Return      :
 */
{
    unsigned int crc16;
    unsigned int temp;
    unsigned char c, flag;

    crc16 = 0xffff;                                /* init the CRC WORD */
    for (num; num>0; num--) {
        temp = (unsigned int) *ptbuf;              /* temp has the first byte */
        temp &= 0x00ff;                            /* mask the MSB */
        crc16 = crc16 ^ temp;                      /* crc16 XOR with temp */
        for (c=0; c<8; c++) {
            flag = crc16 & 0x01;                  /* LSB bit di crc16 is mantained */
            crc16 = crc16 >> 1;                 /* Lsbit di crc16 is lost */
            if (flag != 0)
                crc16 = crc16 ^ 0xa001;          /* crc16 XOR with 0xa001 */
        }
        ptbuf++;                                /* pointer to the next byte */
    }

    crc16 = (crc16 >> 8) | (crc16 << 8);      /* LSB is exchanged with MSB */
    return (crc16);
} /* calc_crc */

```


2.4 Error management

If the received message is incorrect (CRC16 is wrong) the polled slave doesn't answer.

If the message is correct but there are errors (wrong functional code or data) it can't be accepted, so the slave answers with an error message.

The error codes are defined in the following part of the document.

2.5 Timing



TIME	DESCRIPTION	Min & Max VALUES
T1	Time between characters. If this time exceeds the max. time allowed, the message is not considered by device.	Min = 3 msec Max = 99 msec
T2	Slave response time Minimum response delay to Master request.	Min = 10 ms
T3	Time before a new message request from the Master can be issued	Min = 1 ms

**Be careful : among the setup parameters there is a timeout value that may be programmed
The value of 20 msec is suggested to keep compatibility with older IME devices.
The minimum value is 3 msec.**

3.0 COMMANDS

Code 0x03 : reading of one or more consecutive WORDS

Command format :

BYTE	BYTE	MSB	LSB	MSB	LSB		
Device address	Funct. Code	First WORD address		WORDS number		CRC16	

Answer format (containing data) :

BYTE	BYTE	BYTE	MSB	LSB	MSB	LSB		
Device address	Funct. Code	BYTES number	WORD 1		WORD N.		CRC16	

The BYTES number must always match the WORDS number (in the demand) * 2.

Answer format (the demand was wrong) :

BYTE	BYTE	BYTE		
Device address	Funct. Code + 0x80	Error code	CRC16	

Error codes :

- * 0x01 : incorrect functional code
- * 0x02 : wrong first WORD address
- * 0x03 : incorrect data

Code 0x10 : writing of more consecutive WORDS

Command format :

BYTE	BYTE	MSB	LSB	MSB	LSB	MSB	LSB		
Device address	Funct. Code	First WORD address	WORDS number	BYTE numbers	Word Value			CRC16	

Answer format (containing data) :

BYTE	BYTE	MSB	LSB	MSB	LSB		
Device address	Funct. Code	First WORD address	WORD N.			CRC16	

The BYTES number must always match the WORDS number (in the demand) * 2.

Answer format (the demand was wrong) :

BYTE	BYTE	BYTE		
Device address	Funct. Code + 0x80	Error code	CRC16	

Error codes :

- * 0x01 : incorrect functional code
- * 0x02 : wrong first WORD address
- * 0x03 : incorrect data

4.0 VARIABLES

Variables or groups of variables may be required up to 240 BYTES

0x100	U_WORD	Current transformer ratio (KTA)	No unit
0x102	U_WORD	Voltage transformer ratio (KTV)	No unit Format : 1/100 (hundredths) (e.g. KTV = 5 Reading = 500)
0x300	U_WORD	Device identifier	0x1101

Address	Format	Description	Unit
0x1000	UD WORD	Phase 1 : phase voltage	mV
0x1002	UD WORD	Phase 2 : phase voltage	mV
0x1004	UD WORD	Phase 3 : phase voltage	mV
0x1006	UD WORD	Phase 1 : current	mA
0x1008	UD WORD	Phase 2 : current	mA
0x100a	UD WORD	Phase 3 : current	mA
0x100c	UD WORD	Neutral current	mA
0x100e	UD WORD	Chained voltage : L1-L2	mV
0x1010	UD WORD	Chained voltage : L2-L3	mV
0x1012	UD WORD	Chained voltage : L3-L1	mV
0x1014	UD WORD	3-phase : active power	(3)
0x1016	UD WORD	3-phase : reactive power	(3)
0x1018	UD WORD	3-phase : apparent power	(3)
0x101a	U WORD	3-phase : sign of active power	(6)
0x101b	U WORD	3-phase : sign of reactive power	(6)
0x101c	UD WORD	3-phase : positive active energy	(4)
0x101e	UD WORD	3-phase : positive reactive energy	(4)
0x1020	UD WORD	3-phase : negative active energy	(4)
0x1022	UD WORD	3-phase : negative reactive energy	(4)
0x1024	S WORD	3-phase : power factor	1/100 signed
0x1025	U WORD	3-phase : sector of power factor (cap or ind)	0 : PF = 1 1 : ind 2 : cap
0x1026	U WORD	Frequency	Hz/10
0x1027	UD WORD	3-phase : average power	(3)
0x1029	UD WORD	3-phase : peak maximum demand	(3)
0x102b	U WORD	Time counter for average power	minutes
0x102c	UD WORD	Phase 1 : active power	(3)
0x102e	UD WORD	Phase 2 : active power	(3)
0x1030	UD WORD	Phase 3 : active power	(3)
0x1032	U WORD	Phase 1 : sign of active power	(6)
0x1033	U WORD	Phase 2 : sign of active power	(6)
0x1034	U WORD	Phase 3 : sign of active power	(6)
0x1035	UD WORD	Phase 1 : reactive power	(3)
0x1037	UD WORD	Phase 2 : reactive power	(3)
0x1039	UD WORD	Phase 3 : reactive power	(3)
0x103b	U WORD	Phase 1 : sign of reactive power	(6)
0x103c	U WORD	Phase 2 : sign of reactive power	(6)
0x103d	U WORD	Phase 3 : sign of reactive power	(6)
0x103e	UD WORD	Phase 1 : apparent power	(3)
0x1040	UD WORD	Phase 2 : apparent power	(3)
0x1042	UD WORD	Phase 3 : apparent power	(3)
0x1044	S WORD	Phase 1 : power factor	1/100 signed
0x1045	S WORD	Phase 2 : power factor	1/100 signed
0x1046	S WORD	Phase 3 : power factor	1/100 signed
0x1047	U WORD	Phase 1 : power factor sector	0 : PF = 1 1 : ind 2 : cap
0x1048	U WORD	Phase 2 : power factor sector	0 : PF = 1 1 : ind 2 : cap
0x1049	U WORD	Phase 3 : power factor sector	0 : PF = 1 1 : ind 2 : cap
0x104a	U WORD	Phase 1 : THD V1	1/10 %
0x104b	U WORD	Phase 2 : THD V2	1/10 %
0x104c	U WORD	Phase 3 : THD V3	1/10 %
0x104d	U WORD	Phase 1 : THD I1	1/10 %
0x104e	U WORD	Phase 2 : THD I2	1/10 %
0x104f	U WORD	Phase 3 : THD I3	1/10 %

0x1050	UD WORD	Phase 1 : I1 average	mA
0x1052	UD WORD	Phase 2 : I2 average	mA
0x1054	UD WORD	Phase 3 : I3 average	mA
0x1056	UD WORD	Phase 1 : I1 peak maximum	mA
0x1058	UD WORD	Phase 2 : I2 peak maximum	mA
0x105a	UD WORD	Phase 3 : I3 peak maximum	mA
0x105c	UD WORD	(I1+I2+I3) /3	mA
0x105e	UD WORD	Phase 1 : V1 min	mV
0x1060	UD WORD	Phase 2 : V2 min	mV
0x1062	UD WORD	Phase 3 : V3 min	mV
0x1064	UD WORD	Phase 1 : V1 max	mV
0x1066	UD WORD	Phase 2 : V2 max	mV
0x1068	UD WORD	Phase 3 : V3 max	mV
0x106a	UD WORD	3-phase : active partial energy	(4)
0x106c	UD WORD	3-phase : reactive partial energy	(4)
0x106e	U WORD	Run hour meter	Hour
0x106f	U WORD	Not used	-
0x1070	UD WORD	3-phase : active average power	(3)
0x1072	UD WORD	3-phase : reactive average power	(3)
0x1074	UD WORD	3-phase : apparent average power	(3)
0x1076	UD WORD	3-phase : active PMD power	(3)
0x1078	UD WORD	3-phase : reactive PMD power	(3)
0x107a	UD WORD	3-phase : apparent PMD power	(3)

0x1200	U WORD	Current transformer ratio (KTA)	No unit
0x1201	U WORD	Voltage transformer ratio (KTV)	1/10 (**) (tenths) (e.g. KTV = 5 Reading = 50)
0x1202	UD WORD	Device configuration	(1)
0x1204	U WORD	Device identifier	0x1101
0x1205	U WORD	Voltages sequence diagnostic	1 : OK 2 : error

(**) for compliance with older products

0x1500	UD WORD	Positive Active Energy - Low	Wh
0x1502	UD WORD	Positive Active Energy - High	MWh
0x1504	UD WORD	Positive Reactive Energy - Low	varh
0x1506	UD WORD	Positive Reactive Energy - High	Mvarh
0x1508	UD WORD	Negative Active Energy - Low	Wh
0x150A	UD WORD	Negative Active Energy - High	MWh
0x150C	UD WORD	Negative Reactive Energy - Low	varh
0x150E	UD WORD	Negative Reactive Energy - High	Mvarh
0x1510	UD WORD	Partial Active Energy - Low	Wh
0x1512	UD WORD	Partial Active Energy - High	MWh
0x1514	UD WORD	Partial Reactive Energy - Low	varh
0x1516	UD WORD	Partial Reactive Energy - High	Mvarh
0x1518	SD WORD	Signed 3-ph Active Power	W
0x151A	SD WORD	Signed 3-ph Reactive Power	var
0x151C	SD WORD	Signed Phase1 Active Power	W
0x151E	SD WORD	Signed Phase2 Active Power	W
0x1520	SD WORD	Signed Phase3 Active Power	W
0x1522	SD WORD	Signed Phase1 Reactive Power	var
0x1524	SD WORD	Signed Phase2 Reactive Power	var
0x1526	SD WORD	Signed Phase3 Reactive Power	var
0x1528	SD WORD	Signed 3-ph Power Factor	1/1000
0x152A	SD WORD	Signed Phase1 Power Factor	1/1000
0x152C	SD WORD	Signed Phase2 Power Factor	1/1000
0x152E	SD WORD	Signed Phase3 Power Factor	1/1000

0x1530	UD WORD	Apparent power	VA
0x1532	UD WORD	3-phase : active average power	W
0x1534	UD WORD	3-phase : reactive average power	Var
0x1536	UD WORD	3-phase : apparent average power	VA
0x1538	UD WORD	3-phase : active PMD power	W
0x153a	UD WORD	3-phase : reactive PMD power	Var
0x153c	UD WORD	3-phase : apparent PMD power	VA
0x1540	U WORD	Active positive energy wrap around	(*)
0x1541	U WORD	Reactive positive energy wrap around	(*)
0x1542	U WORD	Active negative energy wrap around	(*)
0x1543	U WORD	Reactive negative energy wrap around	(*)

0x1580	U WORD	Phase1 voltage crest factor	1/1000
0x1581	U WORD	Phase2 voltage crest factor	1/1000
0x1582	U WORD	Phase3 voltage crest factor	1/1000
0x1583	U WORD	Phase1 current crest factor	1/1000
0x1584	U WORD	Phase2 current crest factor	1/1000
0x1585	U WORD	Phase3 current crest factor	1/1000
0x1586	U WORD	Phase12 voltage crest factor	1/1000
0x1587	U WORD	Phase23 voltage crest factor	1/1000
0x1588	U WORD	Phase31 voltage crest factor	1/1000

(*) wrap around means : when the main register of the energy value increases over 100 000 000 , the register is then reset to 0 and the wrap around value is incremented by 1

0x1700	UD WORD	Positive Active Energy - Low	Wh
0x1702	UD WORD	Positive Active Energy - High	MWh
0x1704	UD WORD	Positive Reactive Energy - Low	varh
0x1706	UD WORD	Positive Reactive Energy - High	Mvarh
0x1708	UD WORD	Negative Active Energy - Low	Wh
0x170A	UD WORD	Negative Active Energy - High	MWh
0x170C	UD WORD	Negative Reactive Energy - Low	varh
0x170E	UD WORD	Negative Reactive Energy - High	Mvarh
0x1710	UD WORD	Partial+ Active Energy - Low	Wh
0x1712	UD WORD	Partial+ Active Energy - High	MWh
0x1714	UD WORD	Partial+ Reactive Energy - Low	varh
0x1716	UD WORD	Partial+ Reactive Energy - High	Mvarh
0x1718	UD WORD	Partial- Active Energy - Low	Wh
0x171a	UD WORD	Partial- Active Energy - High	MWh
0x171c	UD WORD	Partial- Reactive Energy - Low	varh
0x171e	UD WORD	Partial- Reactive Energy - High	Mvarh
0x1720	SD WORD	Signed 3-ph active power	W
0x1722	SD WORD	Signed 3-ph reactive power	var
0x1724	SD WORD	Signed phase1 active power	W
0x1726	SD WORD	Signed phase2 active power	W
0x1728	SD WORD	Signed phase3 active power	W
0x172A	SD WORD	Signed phase1 reactive power	var
0x172C	SD WORD	Signed phase2 reactive power	var
0x172E	SD WORD	Signed phase3 reactive power	var
0x1730	SD WORD	Signed 3-ph Power Factor	1/100
0x1732	SD WORD	Signed phase1 Power Factor	1/100
0x1734	SD WORD	Signed phase2 Power Factor	1/100
0x1736	SD WORD	Signed phase3 Power Factor	1/100

0x7000	U WORD	Current phase 1 - fundamental	1000
0x7001	U WORD	Current phase 1 - 2nd harmonic (percentage)	1/10 %
-----	-----	-----	-----
0x7031	U WORD	Current phase 1 - 50 th harmonic (percentage)	1/10 %
-----	-----	-----	-----
0x7040	U WORD	Current phase 2 - fundamental	1000
0x7041	U WORD	Current phase 2 - 2 nd harmonic (percentage)	1/10 %
-----	-----	-----	-----
0x7071	U WORD	Current phase 2 - 50 th harmonic (percentage)	1/10 %
-----	-----	-----	-----
0x7080	U WORD	Current phase 3 - fundamental	1000
0x7081	U WORD	Current phase 3 - 2 nd harmonic (percentage)	1/10 %
-----	-----	-----	-----
0x70B1	U WORD	Current phase 3 - 50 th harmonic (percentage)	1/10 %
-----	-----	-----	-----
0x70C0	U WORD	Voltage phase 1 (V12) - fundamental	1000
0x70C1		Voltage phase 1 (V12) - 2 nd harmonic (percentage)	1/10 %
-----	-----	-----	-----
0x70F1	U WORD	Voltage phase 1 (V12) - 50 th harmonic (percentage)	1/10 %
-----	-----	-----	-----
0x7100	U WORD	Voltage phase 2 (V23) - fundamental	1000
0x7101	U WORD	Voltage phase 2 (V23) - 2 nd harmonic (percentage)	1/10 %
-----	-----	-----	-----
0x7131	U WORD	Voltage phase 2 (V23) - 50 th harmonic (percentage)	1/10 %
-----	-----	-----	-----
0x7140	U WORD	Voltage phase 3 (V31) - fundamental	1000
0x7141	U WORD	Voltage phase 3 (V31) - 2 nd harmonic (percentage)	1/10 %
-----	-----	-----	-----
0x7171	U WORD	Voltage phase 3 (V31) - 50 th harmonic (percentage)	1/10 %
-----	-----	-----	-----
0x7200	UD WORD	Current phase 1 - fundamental (rms)	mA
-----	-----	-----	-----
0x7262	UD WORD	Current phase 1 - 50 th harmonic (rms)	mA
-----	-----	-----	-----
0x7280	UD WORD	Current phase 2 - fundamental (rms)	mA
-----	-----	-----	-----
0x72E4	UD WORD	Current phase 2 - 50 th harmonic (rms)	mA
-----	-----	-----	-----
0x7300	UD WORD	Current phase 3 - fundamental (rms)	mA
-----	-----	-----	-----
0x7364	UD WORD	Current phase 3 - 50 th harmonic (rms)	mA
-----	-----	-----	-----
0x7380	UD WORD	Voltage phase 1 (V12) - fundamental (rms)	mV
-----	-----	-----	-----
0x73E2	UD WORD	Voltage phase 1 (V12) - 50 th harmonic (rms)	mV
-----	-----	-----	-----
0x7400	UD WORD	Voltage phase 2 (V23) - fundamental (rms)	mV
-----	-----	-----	-----
0x7462	UD WORD	Voltage phase 2 (V23) - 50 th harmonic (rms)	mV
-----	-----	-----	-----
0x7480	UD WORD	Voltage phase 3 (V31) - fundamental (rms)	mV
-----	-----	-----	-----
0x74E2	UD WORD	Voltage phase 3 (V31) - 50 th harmonic (rms)	mV

0x7500	U WORD	THD I1	1/10 %
0x7501	U WORD	THD I2	1/10 %
0x7502	U WORD	THD I3	1/10 %
0x7503	U WORD	THD V1 (V12)	1/10 %
0x7504	U WORD	THD V2 (V23)	1/10 %
0x7505	U WORD	THD V3 (V31)	1/10 %

(1) -----

Variable			
MSB (BYTE 3)	BYTE 2	BYTE 1	LSB (BYTE 0)
0x2D = Dummy	Pulse Output	Base Comm	Comm Module

Type of data :

0x2D622D2D => 'b--' : Dummy, Pulse out, No Communication, No Module RS485
 0x2D62412d => 'bA-' : Dummy, Pulse out, Base Comm present, No Module RS485
 0x2D624141 => 'bAA' : Dummy, Pulse out, Base Comm present, Module RS485 yes

(3) -----

```
W, var, VA / 100 if KTA*KTV < 5000
W, var, VA           if KTA*KTV >= 5000
```

(4) -----

Transformer ratio	Measurement unit	Display Format	Protocol Format
1 ≤ KTA*KTV < 10	Wh(varh) * 10	xxxxxx.yy k	xxxxxxxxyy
10 ≤ KTA*KTV < 100	Wh(varh) * 100	xxxxxxxx.y k	xxxxxxxxxy
100 ≤ KTA*KTV < 1000	kWh(kvarh)	xxxxxxxxx k	xxxxxxxxxx
1000 ≤ KTA*KTV < 10000	kWh(kvarh) * 10	xxxxxx.yy M	xxxxxxxxyy
10000 ≤ KTA*KTV < 100000	kWh(kvarh) * 100	xxxxxxxx.y M	xxxxxxxxxy

(6) -----

0 : positive
 1 : negative

5.0 SETUP PARAMETERS

NEMO 96HDL parameters may be read and written accordingly to the procedure described in the following.

The variable table to read and write the parameters are located at the same address.

It is allowed to write the setup parameters addressed at 0x2000 and 0x2200 only by a single telegram for each group.

Standard Setup parameters (read and write)

0

Length : 16 BYTES

0x2000	<u>WORD</u>	RFU	
0x2001	<u>WORD</u>	RFU	
0x2002	<u>WORD</u>	RFU	
0x2003	<u>WORD</u>	RFU	
0x2004	<u>WORD</u>	RFU	
0x2005	<u>WORD</u>	Run hour meter active on	0:V1 1:P
0x2006	<u>WORD</u>	RFU	
0x2007	<u>WORD</u>	Rated current	0 : 5A 1 : 1A
0x2008	<u>WORD</u>	Backlight intensity	0: 0% 1: 30% 2: 70% 3:100%
0x2009	<u>WORD</u>	Display contrast	0: level 0 1: level 1 2: level 2 3: level 3
0x200a	<u>WORD</u>	Power Averaging time	0: 5 min 1: 8 min 2: 10 min 3: 15 min 4: 20 min 5: 30 min 6: 60 min
0x200b	<u>WORD</u>	Insertion type	0: 3n-3e 1: 3-3e 2: 3-2e 3: 1n-1e 4: 3n-1e 5: 3-1e
0x200c	<u>WORD</u>	Measure on line 3 of custom page	0: V phase 3 1: V31 2: I phase 3 3: P 3-phase 4: Q 3-phase 5: S 3-phase 6: P phase 3 7: Q phase 3 8: S phase 3 9: P phase 1 10: I phase 1
0x200d	<u>WORD</u>	Measure on line 2 of custom page	0: V phase 2 1: V23 2: I phase 2 3: P 3-phase 4: Q 3-phase 5: S 3-phase 6: P phase 2 7: Q phase 2 8: S phase 2 9: Frequency 10: I phase 1

0x200e	U_WORD	Measure on line 1 of custom page	0: V phase 1 1: V12 2: I phase 1 3: I Neutral 4: 3-phase 5: Q 3-phase 6: S 3-phase 7: P phase 1 8: Q phase 1 9: S phase 1 10:PF 3-phase
0x200f	U_WORD	RFU	

E.g. Request

FF 03 20 00 00 10 5A 18

Answer :

FF	03	20	0x2000	0x2001	0x2002	0x2003	0x2004	0x2005	0x2006	0x2007	0x2008
			w0	w1	w2	w3	w4	w5	w6	w7	w8
			0x2009	0x200a	0x200b	0x200c	0x200d	0x200e	0x200f		
			w9	w10	w11	w12	w13	w14	w15		CRC WORD

FF	03	20	00 00 00 05 00 00 00 03 00 0A 00 00 00 00 00 00 00 01	00 01 00 00 00 00 00 03 00 02 00 01 00 00 BC B2
----	----	----	---	---

w0, w1, w2, w3, w4, w6, w15 are not used.

Output options parameters (read and write)

Length : 24 BYTES

0x2200	<u>WORD</u>	RFU	
0x2201	<u>WORD</u>	RFU	
0x2202	<u>WORD</u>	RFU	
0x2203	<u>WORD</u>	RFU	
0x2204	<u>WORD</u>	RFU	
0x2205	<u>WORD</u>	RFU	
0x2206	<u>WORD</u>	RFU	
0x2207	<u>WORD</u>	RFU	
0x2208	<u>WORD</u>	RFU	
0x2209	<u>WORD</u>	RFU	
0x220a	<u>WORD</u>	RFU	
0x220b	<u>WORD</u>	RFU	
0x220c	<u>WORD</u>	RFU	
0x220d	<u>WORD</u>	RFU	
0x220e	<u>WORD</u>	RFU	
0x220f	<u>WORD</u>	RFU	
0x2210	<u>WORD</u>	RFU	
0x2211	<u>WORD</u>	RFU	
0x2212	<u>WORD</u>	RFU	
0x2213	<u>WORD</u>	RFU	
0x2214	<u>WORD</u>	RFU	
0x2215	<u>WORD</u>	Pulse duration	0: 50 ms 1: 100 ms 2: 200 ms 3: 300 ms 4: 400 ms 5: 500 ms
0x2216	<u>WORD</u>	Pulse weight	0: 0.01 k 1: 0.1 k 2: 1.0 k 3: 10.0 k 4: 100,0 k 5: 1,0 M 6: 10,0 M
0x2217	<u>WORD</u>	Positive Energy type used for the pulse output	0: active 1: reactive

E.g. Request

FF 03 22 00 00 18 5A 66

Answer :

FF 03 30	0x2200	0x2201	0x2202	0x2203	0x2204	0x2205	0x2206	0x2207	0x2208
	W0	W1	W2	W3	W4	W5	W6	W7	W8
	0x2209	0x220a	0x220b	0x220c	0x220d	0x220e	0x220f	0x2210	0x2211
	W9	W10	W11	W12	W13	W14	W15	W16	W17
	0x2212	0x2213	0x2214	0x2215	0x2216	0x2217	CRC WORD		
	W18	W19	W20	W21	W22	W23			
FF 03 30	00 00	00 00	00 00	00 00	00 00	00 00	00 00	00 00	00 00
	00 00	00 00	00 00	00 00	00 00	00 00	00 00	00 00	00 00
	00 00	00 00	00 00	00 00	00 02	00 01	6D C1		

W0 .. W20 are not used.

Procedure to write

NEMO 96 HDLe parameters may be written accordingly to the procedure described in the following.

Master Unlock Key Writing

Every write operation must be preceded by a “Master Unlock Key” command.

Address 0x2700 : write word with value = 0x5AA5 (Master Unlock Key)

Reset of NEMO 96 HDLE

Any writing operation of any parameter will have effect **only** in the volatile memory (RAM).

After any writing operation of parameters described in the following of the document, if necessary to go back to the default then it is mandatory to send the following commands :

Address 0x2700 : write word with value = 0x5AA5 (Master Unlock Key)

Address 0x2800 : write word with value = 0xFFFF (any value)

This command will reset the NEMO 96 HDLE and in this way all changes will be lost so returning to the previous conditions.

EEPROM savings

If it is necessary to save the new parameters in EEPROM it is mandatory to send these following messages :

Address 0x2700 : write WORD with value = 0x5AA5 (Master Unlock Key)

Address 0x2600 : write WORD with value = 0xFFFF (any value)

Write address table

Address	Format	Description	Value
0x100	U_WORD	Write Current transformer ratio	1 - 9999
0x102	U_WORD	Write Voltage transformer ratio (e.g. 4.3 Reading 43)	1/10
0x2000	16 U_WORD	Write Standard setup parameters	(16)
0x2200	24 U_WORD	Write Programming parameters of pulse output (slot 2)	(16)
0x2400	U_WORD	Reset Hour Meter, Maximum Powers, Maximum Voltages, Maximum Currents, Minimum Voltages, Active Partial Energy, Reactive Partial Energy	(12)
0x2600	U_WORD	Saving in EEPROM parameters changed by Remote commands	(13)
0x2700	U_WORD	Enable Remote Writing Operation	(14)
0x2800	U_WORD	Load previous setup parameters stored in EEPROM	(15)

(12) To reset desired measurements write the following word (in binary) :

0|0|0|0|0|0|0|0|b8|b7|b6|b5|b4|b3|b2|b1|b0

b0 = 1 => Reset Hour Meter
 b1 = 1 => Reset Peak Maximum Demand
 b2 = 1 => Reset Maximum Voltage values
 b3 = 1 => Reset Maximum Current values
 b4 = 1 => Reset Minimum Voltage values
 b5 = 1 => Reset Active Partial Energy
 b6 = 1 => Reset Reactive Partial Energy
 b7 = 1 => Reset Counter Input 1 (Sw > 1.02)
 b8 = 1 => Reset Counter Input 2 (Sw > 1.02)

b9 .. b15 = 0

(13) Write any value to save the new parameters changed by Remote commands

(14) To do any remote programming write operation, it's mandatory to write a safety key = 0x5AA5.

(15) Write any value to abort any remote programming write operation and reload the previous values.

(16) The parameters are read and written with the same sequence.