

## Signalling auxiliaries DX<sup>3</sup>



Pack	Cat.Nos	Signalling auxiliaries prong busbar adapted	Pack	Cat.Nos	Signalling auxiliaries fork busbar adapted		
		<p>To fit on the left-hand side of DX<sup>3</sup> and TX<sup>3</sup> devices                      Maximum number of auxiliaries per device:                      - 3 signalling auxiliaries or                      - 2 signalling auxiliaries + 1 remote tripping auxiliary                      Allow insertion of the supply busbar, top side                      No tool required for joining together the auxiliary and the main device.</p>			<p>To fit on the left-hand side of DX<sup>3</sup> and TX<sup>3</sup> devices                      Maximum number of auxiliaries per device:                      - 3 signalling auxiliaries or                      - 2 signalling auxiliaries + 1 remote tripping auxiliary                      Allow insertion of supply busbar, bottom side                      No tool required for joining together the auxiliary and the main device.</p>		
1	4 062 58	<p><b>Auxiliary contact</b>                      6 A - 250 V<math>\sim</math> (changeover switch)                      For MCBs, RCBOs, RCCBs, isolating switches or remote trip isolating switches                      Indicates the position of the contacts of its associated device.</p>	0.5	1	4 062 50	<p><b>Auxiliary contact</b>                      6 A - 250 V<math>\sim</math>(changeover switch)                      For MCBs, RCBOs, RCCBs, isolating switch or remote trip isolating switch                      Indicates the position of the contacts of its associated device</p>	0.5
1	4 062 60	<p><b>Fault signalling contact</b>                      6 A - 250 V<math>\sim</math> (changeover switch)                      For MCBs, RCBOs, RCCBs,                      Indicates the fault tripping of its associated device</p>	0.5	1	4 062 52	<p><b>Fault signalling contact</b>                      6 A - 250 V<math>\sim</math> (changeover switch)                      For MCBs, RCBOs, RCCBs,                      Indicates the fault tripping of its associated device</p>	0.5
1	4 062 62	<p><b>Auxiliary or fault signalling contact</b>                      6 A - 250 V<math>\sim</math> (changeover switch)                      For MCBs, RCBOs, RCCBs                      Allows the choice between the two functions</p>	0.5	1	4 062 56	<p><b>Auxiliary or fault signalling contact</b>                      6 A - 250 V<math>\sim</math> (changeover switch)                      For MCBs, RCBOs, RCCBs                      Allows the choice between the two functions</p>	0.5
1	4 062 66	<p><b>Auxiliary + fault signalling contact or auxiliary contact + auxiliary contact</b>                      6 A - 250 V<math>\sim</math> (changeover switch)                      For MCBs, RCBOs, RCCBs</p>	1	1	4 062 64	<p><b>Auxiliary + fault signalling contact or auxiliary contact + auxiliary contact</b>                      6 A - 250 V<math>\sim</math> (changeover switch)                      For MCB, RCBOs, RCCBs</p>	1