


Connected three-phases energy meter

4 121 75



Requires the installation of a :


Gateway module



/
OR
/

Any kind of
« With Netatmo »
gateway

Composition



Not supplied: Possibility to use the extension kit (+ 1 or 3 meters):
4 149 15/16



U	I	F	Accuracy of measuring chain*	Measure
-5°C +45°C	From 2A to 125A by Phase	2,4-2,4835Ghz <100 mW	+/-1% under 125A	Global or per circuit

CE Directive

Compliant with the following European directive:
Low voltage directive (LVD) 2014/35/UE
Electromagnetic compatibility (CEM) n° 2014/30/UE

* Module + Coil (without extension kit)

Safety instructions

This product should be installed in compliance with installation rules, preferably by a qualified electrician. Incorrect installation and/or incorrect use can lead to risk of electric shock or fire. Before carrying out the installation, read the instructions and take account of the product's specific mounting locations. Do not open up, dismantle, alter or modify the device except where specifically required to do so by the instructions. All **Legrand** products must be opened and repaired exclusively by personnel trained and approved by **Legrand**. Any unauthorised opening or repair completely cancels all liabilities and the rights to replacement and guarantees. Use only **Legrand** brand accessories.




1 Preparation, connection




OFF

Turn off the power at general circuit breaker



Wiring

To be used only on a three-phases network



The module is powered from 100 to 240V~ between Neutral (N) and Phase 3 (V3).

A three-phases circuit breaker with a rating of C2 to C16 is required according on the section of cable used, to supply and protect the connected three-phases energy meter. If conditions allow, the existing electrical protections in the electrical panel can be reused for this purpose.

— N (neutral) = Blue

— L1 (phase1) = Brown

— L2 (phase2) = Black

— L3 (phase3) = Grey

② Add the **three-phases energy meter** in a connected installation




OFF

Turn off the power at **general circuit breaker**



ON


Turn on the power at the **general circuit breaker** once the installation is completed and controlled*



* After wiring the system, replace the modular front plate, so that no active live part under tension is accessible.


③ Finalize the installation in the Legrand Home + Control app

Download the Home + Control App and follow the instructions for adding the connected product in your setup.



**Connected three-phases energy meter resetting :
to remove it from a connected installation**

Press and hold over 5 seconds on the setting button until the LED on the setting button be fixed red.
It is no longer paired with the gateway.
(Gateway module / Gateway power outlet,...)



www.legrand.com/ecatalogue/

LEGRAND - Pro and Consumer Service - BP 30076
87002 LIMOGES CEDEX FRANCE • www.legrand.com

EU SIMPLIFIED DECLARATION OF CONFORMITY

The undersigned,

Legrand

declares that the radio equipment listed on this instruction sheet
are compliant to the directive 2014/53/UE.

The full text of the EU declaration of conformity
is available at the following website:

www.legrand.com/ecatalogue